

Heathkit TC-3 Einstellungen						
Röhrenbezeichnung	Type	Filament	Plate	Top	Bottom	Bemerkungen
0A2	4	off	40	AE	BDG	good tube reads 10
5879	1	6.3	26	AGHJ	CD	
6550	3	6.3	21	CDE	GH	
6973	4	6.3	19	(AH)(CF) J	EG	
7199 (1)	1	6.3	19	BCG	EF	
7199 (2)	2	6.3	21	AJ	EH	
7868	3	6.3	20	(AG)(BF) J	CE	
12AT7 - ECC81 (1)	2	6.3	24	AB	CJ	
12AT7 - ECC81 (2)	2	6.3	24	FG	HJ	
12AU7 - ECC82 - E82CC (1)	2	6.3	25	AB	CDE	
12AU7 - ECC82 - E82CC (2)	2	6.3	25	FG	DEH	
12AX7 - ECC83 - E83CC (1)	1	6.3	20	AB	CDE	
12AX7 - ECC83 - E83CC (2)	1	6.3	20	FG	DEH	
12BH7 (1)	2	6.3	21	AB	CDE	
12BH7 (2)	2	6.3	21	FG	DEH	
5AR4 - GZ34 (1)	3	6.3	26	D	H	
5AR4 - GZ34 (2)	3	6.3	26	F	H	
5U4 (1)	3	5.0	35	D	H	
5U4 (2)	3	5.0	35	F	H	
6AN8 (1)	2	6.3	22	AB	CE	
6AN8 (2)	2	6.3	22	FGH	EJ	no open element test on F
6AU6	2	6.3	22	ABEF	DG	
6AU8 (1)	2	6.3	21	BC	AD	
6AU8 (2)	2	6.3	21	GHJ	DF	no open element test on J
6BJ6	2	6.3	22	AEFG	BD	
6CG7 (1)	2	6.3	22	AB	CDE	
6CG7 (2)	2	6.3	22	FG	DH	
6CY7 (1)	1	6.3	20	FG	DH	
6CY7 (2)	3	6.3	20	ABC	DJ	
6EU7 (1)	2	6.3	24	EF	BD	
6EU7 (2)	2	6.3	24	GH	BJ	
6J5	2	6.3	24	CE	GH	
6J7	2	6.3	29	CDN	AEGH	
6L6 - 6L6G - VT115	3	6.3	27	CDE	GH	
6L6GA - VT115A - EL37	3	6.3	23	CDE	GH	
6L6GB - 5881	3	6.3	20	CDE	GH	
6SC7 (1)	3	6.3	33	BC	FG	
6SC7 (2)	3	6.3	33	DE	FG	
6SJ7	2	6.3	27	DFH	CEG	
6SK7	3	6.3	30	DFH	CEG	
6SL7 (1)	3	6.3	28	AB	CG	
6SL7 (2)	3	6.3	28	DE	FG	
6SN7 (1)	2	6.3	26	AB	CG	
6SN7 (2)	2	6.3	26	DE	FG	
6V6	3	6.3	29	CDE	AGH	
6X4 (1)	3	6.3	30	A	DG	
6X4 (2)	3	6.3	30	F	DG	
ECL86 - 6GW8 (1)	1	6.3	20	AJ	BE	
ECL86 - 6GW8 (2)	3	6.3	20	CFH	EG	
EL34 - 6CA7	3	6.3	18	ACDE	GH	
EL84 - 6BQ5	3	6.3	22	ABGJ	CD	
Hinweis: Daten aus Manual TC-3 zusammengestellt						